



#### SEQUENCE OF CONSTRUCTION

1. REMOVE THE EXISTING HMA SURFACE.
2. REMOVE AND REPLACE FULL DEPTH PATCHES.
3. REPLACE HMA SURFACE.

#### GENERAL NOTES

1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12" WIDER ON EACH SIDE OF THE TRENCH.
2. FOR BASIS OF PAYMENT SEE SPECIAL PROVISION "PATCHING WITH HMA OVERLAY REMOVAL".

# PAVEMENT PATCHING FOR HMA SURFACED PAVEMENT

**442-1**